


# KLR 206 RECEIVER



**note: connect the converter power leads to the input receiver power**

**Warning: make sure the motor is isolated from all track wiring.**